


Peterbilt 337 Eco-Pur Mounting Location

This shows the mounting location on the right side frame rail.



This shows the unit mounted using the center mounting holes in the Eco-Pur bracket. The holes should be drilled in the frame rail approximately 2 inches from the top of the frame rail into the side rail.



This is the completed installation.
Make sure to check clearances with
the hood closed.

