


Detroit Series 60 Supply and Return Port Location

This photo shows the location of the supply port on the engine. This port is located on the right (passenger) side of the engine toward the rear of the engine. This application has a hose in the rear port, some have a sending unit, and some simply have another plug. Either of these 2 ports may be used.



This photo shows the return hose connection at the bottom of the oil pan on the right (passenger) side. Make certain that the arrows on the return line check valve are pointed towards the oil pan.

