

Volvo D12 Port Locations

Volvo D12 Supply Port

Located on the left (driver) side of the engine between the ECM and the starter.



Volvo D12 Return Port

Located on the right (passenger) side of the engine. The lack of additional return ports on the opposite side dictates that the unit be mounted on this side also.

